


# INSTRUCTION MANUAL

## PUMP/LAMP/POWER BANK SOLAR



### Use

**Air Pump:**  
Press the 'Air Pump' switch twice to start the operation, and continue holding the 'Air Pump' switch to shift the Air Pump into soft mode.

**Lighting:**  
Press the "Light" Switch shift mode, from 20% / 50% / 100%

### Input Charger

1. Solar Power

Put solar panel upwards under the sunlight for charging.

2. Type C input Charge

Connect the Type C cable to the AC adapter, etc. The charging indicator blinks during input charging, and all four indicators are on when charging is complete, indicating that the device is fully charged.

### Cautions

- To maintain the pump's optimal performance, avoid continuous use for more than 10 minutes.
- Do not submerge the pump underwater.
- Keep the inflation and deflation ports clean.
- This is not a toy; children under the age of 12 must be supervised by an adult when using the pump.
- Avoid looking directly into the LED as it may cause damage to your eyes.
- When the product's last indicator keeps blinking, the battery power is insufficient and needs to be charged via a 5V/2A battery or solar power. Avoid completely depleting the power.
- Do not store the product with a completely discharged battery for extended periods. Charge the batteries at least once every 3 months during storage.